NLR pharmaceutical



I Application

The NLR valve is a proportional pneumatically actuated valve designed for flow control in installations of the pharmaceutical industries.

It is widely used to control the pressure of a water loop with a pressure transmitter (PID) when the loop is controlled by neither a flowmeter nor a frequency converter of the pump.

I Operating principle

The position sensor instantly controls the operating position to keep the valve in the position determined by the user (PD function) or by a process parameter (PID function). The operation position can be programmed by:

- a standard input signal sent by en external element (e.g. a sensor).

- an internal controller integrated into the positioner. The signal is sent form a keyboard.

I Diseño y características

Normally closed valve (standard version). Equal percentage regulation shaft. 360° adjustable body. Compact design. Dual function positioner: -PD: position controller -PID: process controller Easy assembly/disassembly by loosening the clamp. Standard connections: Clamp OD. Traceability of components.

I Materials

Parts in contact with the productAISI 316LOther stainless steel partsAISI 304GasketsEPDM according to FDA 177.2600Internal surface finish $Ra \le 0,5 \, \mu m$ External surface finishbright polish





Regulating Seat Valve

NLR pharmaceutical

I Options

Steam barrier (if shaft sterilisation is required). Jacketed body. Larger actuator sizes. Gaskets: NBR or FPM. Connections: weld. Material and surface roughness certificates.

I Technical specifications


Available sizes Working temperature

Max.working pressure Compressed air pressure Air supply connections Voltage Signal

DN 1" - DN 4" -10 °C to +121 °C (EPDM) +140 °C (SIP, max. 30 min) 10 bar 6-8 bar G1/8" (BSP) 24 V DC 4...20 mA

14 °F to 250 °F 284 °F 145 PSI 87-116 PSI





DN	Α	В	С	D	H1	Х
DN-1"	50	55		86	425	
DN-1 ½"	60	65		86	440	
DN-2"	70	80	105	112	500	13
DN-2 1/2"	80	90	105	145	610	
DN-3"	90	100		145	625	
DN-4"	125	120		168	690	16



The information contained in this brochure is for guidance only. We reserve the right to modify any material or feature without notice in advance. For further information, please, consult our web site. vw.inoxpa.com



FTphNLR. 1.EN-0308

Regulating Seat Valve

NLR pharmaceutical

I Dimensioning

In the case of the pressure regulation, it is necessary to indicate the range of the pressure to regulate (inlet/outlet pressure) and the valve inlet flow.

In the case of the flow regulation, it is necessary to indicate the flow range to regulate (valve outlet) and the valve inlet pressure.

The NLR is an equal percentage flow characteristic valve.

Khe Kv factor is usually used to calculate the dimensions of this kind of valves, the factor allow us to relate the pressure drop and the flow.

The Kv factor is defined as the flow of water through a valve in cubic meters per hour with a pressure drop of 1 bar (see table below).

VALVE DIAMETER	Kv (m³/h) 100% opening	Kv (m³/h) 50% opening
DN-25	13	6
DN-40	31	15
DN-50	59	20
DN-65	87	33
DN-80	140	48
DN-100	178	59
DN-1"	9	4
DN-1 ½"	24	10
DN-2"	48	19
DN-2 ½"	71	26
DN-3"	106	39



The Kv is calculated for water at 5-30°C.

The required K_V (K_{V_R}) for products with low viscosity and density can be calculated by means of this formula: $K_{V_R} = Q/\sqrt{\Delta P}$ (for viscous products, consult the technical department).

Q (required flow in $m^{3/h}$) ΔP (pressure drop in bar: inlet pressure minus outlet pressure)

The selected Kv (Kv_s) index must be higher than the required Kv_R to ensure a sifficient margin for control. Thus, a safety factor is applied by means of the formula: $Kv_s = Kv_R / 0.7$.

Example:

Q= 15 m³/h ΔP = 1 bar Kv_R = Q/\ ΔP = 15 Kv_S = Kv_R / 0,7 = 21,43 - According to the result, the most adequate valve is the DN 40 with the maimum index of 31 m³/h (Kv at 100% opening). In inches, the most adequate valve is the DN 1 $\frac{1}{2}$ ".

For calculation in other units: $Cv = 1.16 \times Kv$ (gallon/minute and psi)

NB: Remember that the NLR valve is not a shut-off valve and its code includes neither positioner nor potentiometer.





