# Differential Pressure Gauge with limit switch contact assembly

# Measuring Unit: 2 Bourdon Tubes / 1 Pointer Stainless Steel Case with Bayonet Ring, N Standard (DiRZCh) or with Oilfilling (DiRZChOe)

Acc. Class. 1.6 NCS 160 Models

DiRZCh 160 DiRZChOe 160

This data sheet contains information on the ordering text and the minimum pressure ranges of differential pressure gauges with bourdon tube model DiRZCh / DiRZChOe with limit switch contact assembly, as well as drawings with the position of the electrical connection.

**Data sheet 5111** basically contains the details and ordering information for these basic models without limit switch contact assembly. These information are also valid for the version with limit switch contact assembly, as far as deviations are not mentioned

Model code for filled versions with limit switch contact assembly:  ${\tt DiRZCh} {\bf Oe}$ 

A special oil filling instead of glycerine is used as case filling.

Detailed description to the function and the use of our limit switch contact assemblies can be found on **general information leaflet** 9000

Further information, especially to the use of different switching operations can be found on the data sheets of the corresponding limit switch contact assemblies.

**Electromechanical** limit switch contact assembly data sheet **9100** (standard- and magnet contact)

Inductive limit switch contact assembly data sheet 9200

Electronical limit switch contact assembly data sheet 9201

# **Minimum Pressure Ranges**

Every pressure gauge needs directive forces of the measuring element for the operation of the limit switch contact assembly. An installation is only possible for the below mentioned pressure ranges 1)

Model	Minimum					
Limit switch	pressure range					
contact assembly	in bar 1)					
1 x standard	1.0					
1 x standard	1.6					
1 x standard	4.0					
1 x magnetic	1.6					
1 x magnetic	2.5					
1 x magnetic	4.0					
1 x inductive	1.0					
1 x inductive	1.6					
1 x inductive	4.0					
1 x electronic	1.0					
1 x electronic	1.6					
1 x electronic	4.0					

<sup>1)</sup> lower pressure ranges upon request

The set point pointers for pressure gauges with 3 limit values are not all necessarily adjustable on top of each other. You should always indicate which pointers should be adjustable on top of each other, resp. where the set point pointers should be.

Because of increased contact resistances at the mechanical switch contacts you should prefer electronical limit switch contact assemblies for the filled version



#### Window

Laminated safety glass

# **Electrical Connection**

- for mechanical limit switch contact assembly (standard and magnetic contact)
   Universal plug connector
- for inductive limit switch contact assembly Terminal box

Position of the connection right at the case (topview of the dial), for version front flange (Fr) at the back of the case (compare drawings on the reverse side)

The universal plug connector has got 6 connections and one ground terminal. The terminal box has got 6 connections.

# Ordering Information:

The ordering code of the particular models (compare data sheet 5111, but filled version DiRZCh $\underline{Oe}$ ) is being completed by the

- code letters for the model of the limit switch contact assembly
  - $\boldsymbol{S},\,\boldsymbol{M},\,\boldsymbol{I},\,\boldsymbol{E}$  and the
- code letter for the switching operation:
  e.g. 1, 2, 11, 12, 21, 22 etc.,
  compare data sheet 9100, 9200 resp. 9201

#### Examples for ordering codes:

- DiRZChOe 160–3, 0-10 bar, G ½ B, I1
- DiRZCh 160–3, Fr, ½" NPT, 0-6 bar, M12



Sales and Export South, West, North

# ARMATURENBAU GmbH

Manometerstraße 5 • D - 46487 Wesel - Ginderich Tel.:+49(0)2803/9130-0 • Fax:+49(0)2803/1035 armaturenbau.com • mail@armaturenbau.com



Subsidiary Company, Sales and Export East

MANOTHERM Beierfeld GmbH Am Gewerbepark 9 • D-08344 Grünhain-Beierfeld Tel.:+49(0)3774/58–0 • Fax:+49(0)3774/58–545 manotherm.com • mail@manotherm.com

**5119** 5/09

# Case Configurations, Code Letters, Dimensional Data and Weight

Deviations compared to the basic model data sheet 5111:

• Dimensional data b, b1 (front-to-back size) , see table below


The remaining dimesions can be found on data sheet 5111.


The exact position of the plug connector, resp. the terminal box is shown on the drawings (see below).

Deviating mounting only upon request and including additional costs.

Bottom connection parallel one behind the other


# Universal plug connector / Terminal box





Bottom connections parallel one behind the other, rear mounting flange for surface mounting (Rh)


# Universal plug connector / Terminal box



# only model DiRCh 160 (standard version):

bottom connections parallel one behind the other front flange for panel mounting (Fr)

# Universal plug connector / Terminal Box



Version Fr = non-removable front flange for panel mounting with slotted holes and removable cover ring

# Dimensional data (mm/ inches) and weights (kg / lb)

Nominal Case Size	а	a1	b	b1	D	h ±1	m	r	r1	0	01	SW	Weight ( DiRChZ	approx.) DiRChZOe
160	17	20.5	138	141.5	161	117	31	117	27	3	37	22	1.800	3.800
<b>(6")</b>	. <b>67</b>	<b>.80</b>	<b>5.43</b>	<b>5.57</b>	<b>6.34</b>	<b>4.61</b>	<b>1.22</b>	<b>4.61</b>	<b>1.06</b>	. <b>12</b>	<b>1.46</b>	<b>.87</b>	<b>3.96</b>	<b>8.38</b>

You have to add 12 mm (0.47") to the dimensions B and B1 for two inductive or electronical limit switch contact assemblies with **the same** switching operation (I 11, I 22, resp. E 11, E 22, also for triple limit switch contact assemblies).

Technical changes, replacement of materials and errors excepted